

MANUAL DATA UPLOAD

What you will need:

- The modem assigned by the operator (including power supply and phone cable)

1. Plug In Modem

To plug in the modem:

- a. Plug a telephone line into either telephone jack on the modem using a dedicated analog line.
- b. Plug the power cord into the modem and into an electrical outlet.



SCRAM Modem

In 30 seconds, the **red** and **green** lights on the modem begin to *blink* alternately, indicating that the modem is communicating with the network.

2. Wake Up Bracelet

When the **red** and **green** lights turn off, wake up the SCRAM Bracelet.

To wake up the bracelet:

- a. Momentarily place the magnet on the top right side of the bracelet.



Placing Magnet on Bracelet

In approximately 15 seconds, the bracelet pump will run—indicated by a buzz.

In approximately 30 seconds, the solid **red** light on the modem will turn on. This indicates that the modem and the bracelet are communicating.

After a maximum of 45 seconds, the solid **red** light turns off.

3. Unplug and Re-plug In Modem

- a. If the **red** and **green** lights do NOT begin to *blink* in twenty seconds, unplug the power cord and phone line, wait three seconds, and plug the power cord and phone cord back into the modem.

In 30 seconds, the **red** and **green** lights on the modem begin to *blink* alternately.

After approximately 2 minutes, the **red** and **green** lights will turn off.